

## **Windows Servers**

### **Assignment 1 – Creating the basis for lab environment**

#### **Task 1 – Acquire images**

1. Copy images from \\ghost.labranet.jamk.fi\temp\partla to your workstations D-drive
  - a. Windows Server 2016 Evaluation
  - b. Windows 10 Evaluation
  - c. VyOS 1.18

#### **Task 2 – Learn VirtualBox guide by heart**

1. While copying/downloading images, read the VirtualBox helper guide
2. Create directories mentioned in VirtualBox helper guide
3. Apply VirtualBox settings mentioned in VirtualBox helper guide

#### **Task 3 – Create base templates for servers and workstations, create router**

1. Create three (3) Virtual Machines in Virtual Box using the information below
  - a. First VM: Server 2016
    - i. Name: server-2016-template or similar
    - ii. Type: Microsoft Windows
    - iii. Version: Windows 2016 (64-bit)
    - iv. Memory: 2048 MB
    - v. Disk: 32 GB
      1. VDI

2. Dynamically allocated

vi. Settings -> General -> Advanced -> Clipboard & Drag'n'Drop -> Bidirectional

vii. Settings -> Storage

1. Mount Server 2016 Evaluation ISO

viii. Settings -> Network

1. Adapter 1 -> Enable

2. Attached to: Bridged Adapter (Ethernet Connection)

b. Second VM: Windows 10

i. Name: windows-10-template or similar

ii. Type: Microsoft Windows

iii. Version: Windows 10 (64-bit)

iv. Memory: At least 1536 MB (2048 Recommended)

v. Disk: 32 GB

1. VDI

2. Dynamically allocated

vi. Settings -> General -> Advanced -> Clipboard & Drag'n'Drop -> Bidirectional

vii. Settings -> Storage

1. Mount Windows 10 Evaluation ISO

viii. Settings -> Network

1. Adapter 1 -> Enable

2. Attached to: Bridged Adapter (Ethernet Connection)

c. Third VM: VyOS 1.18

i. Name: fw.YourStudentID.local (ie. fw.a1234.local)

ii. Type: Linux

iii. Version: Debian (64-bit)

iv. Memory: 512 MB

v. Disk: 2 GB

1. VDI
  2. Dynamically allocated
- vi. Settings -> Display
1. Reduce memory to minimum (1MB)
- vii. Settings -> Storage
1. Mount VyOS 1.18 ISO
- viii. Settings -> Network
1. Adapter 1,2,3 and 4 -> Enable
    - a. Adapter 1
      - i. Attached to: Bridged Adapter (Ethernet Connection)
    - b. Adapter 2
      - i. Attached to: Internal Network
      - ii. Name: transit
    - c. Adapter 3
      - i. Attached to: Internal Network
      - ii. Name: srv
    - d. Adapter 4
      - i. Attached to: Internal Network
      - ii. Name: mgmt.

## **Task 4 – Installation & Customization**

1. Launch VMs
2. Install operating systems
  - a. Server 2016 – Datacenter edition has a few features the standard doesn't
  - b. Choose Desktop Experience (Try Server Core at some point though)
  - c. Vynos -> <https://wiki.vynos.net/wiki/Installation>
    - i. After you've completed installing VyOS

1. Sudo poweroff
2. Remove VyOS ISO from Storage settings (otherwise you're running it from live image)
3. Launch VM
  - a. `sudo dpkg-reconfigure keyboard-configuration`
  - b. Reboot after
3. Install VirtualBox Guest Additions to Server 2016 and Windows 10 VMs
  - a. Virtualbox Dropdown -> Devices -> Insert Guest Additions CD image
    - i. This PC -> CD Drive "VirtualBox Guest Additions" -> VBoxWindowsAdditions-amd64
  - b. Install optional software at this point
  - c. Some useful software: Mozilla, Putty, WinSCP, Wireshark
4. Run sysprep in Server 2016 and Windows 10
  - a. Generalize
  - b. Out-of-Box Experience
  - c. Shutdown

**NOTE! No need to touch these anymore. If you break a server or workstations, clone a new one from these template VMs. Do not use VirtualBox snapshots if possible.**

## Task 5 – Clone VMs

1. Create four (4) clones of Server 2016
  - a. Reinitialize the MAC address of all network cards!
  - b. Names:
    - i. dc1.YourStudentID.local (ie. dc1.a1234.local)
    - ii. dc2.YourStudentID.local (ie. dc2. a1234.local)
    - iii. fs1.YourStudentID.local (ie. fs1. a1234.local)
    - iv. fs2.YourStudentID.local (ie. fs2. a1234.local)

- c. Change the network settings of Adapter 1 on all servers
  - i. Attached to: Internal Network
  - ii. Name: srv
- 2. Create one (1) clone of Windows 10
  - a. Reinitialize the MAC!
  - b. Linked Clone
  - c. Name: mgmt-ws-01.YourStudentID.local (ie. mgmt-ws-01.a1234.local)
  - d. Change the network settings of Adapter 1
    - i. Attached to: Internal Network
    - ii. Name: mgmt.

## Task 6 – Configure hostnames and addressing

- 1. Configure VyOS network interfaces
  - a. Enter configuration mode

```
vyos@vyos$ configure
```

```
set interfaces ethernet eth0 address dhcp
set interfaces ethernet eth0 description WAN
set interfaces ethernet eth1 address 10.255.255.1/24
set interfaces ethernet eth1 description TRANSIT
set interfaces ethernet eth2 address 10.20.10.1/24
set interfaces ethernet eth2 description SRV
set interfaces ethernet eth3 address 10.20.20.1/24
set interfaces ethernet eth3 description MGMT

set service ssh port 22

set nat source rule 10 outbound-interface eth0
set nat source rule 10 source address 10.0.0.0/8
set nat source rule 10 translation address masquerade
set nat source rule 10 description NAT-ALL

commit

save
```

2. Launch cloned VMs dc1, dc2, fs1 and fs2
3. Configure hostnames to match those in VM names (use the host part of the dns name = dc1 for dc1.a1234.local)

**a. QUESTION: How do you configure hostnames using PowerShell? shut**

```
PS C:\Users\Administrator> Rename-Computer -NewName dc1 -LocalCredential WIN-QU0NR3TM3DU\Administrator -PassTh
HasSucceeded OldComputerName NewComputerName
-----
True WIN-QU0NR3TM3DU dc1
WARNING: The changes will take effect after you restart the computer WIN-QU0NR3TM3DU.
```

4. Configure network interfaces to match the IP addressing scheme described in the topology picture
  - a. Use LabraNet DNS servers for dc1 and dc2
    - i. 192.168.40.21, 192.168.40.22

- b. Use dc1 and dc2 IP addresses as DNS server addresses for fs1 and fs2

**c. QUESTION: How do you configure IP addressing using PowerShell?**

```
PS C:\Users\m3227> New-NetIPAddress -dc1 "Wired Ethernet Connection" -IPv4Address "10.20.10.10" -PrefixLength 24 -DefaultGateway 10.20.10.1
```

**d. QUESTION: How do you configure DNS server addresses using PowerShell?**

```
PS C:\Users\m3227> Set-DnsClientServerAddress -dc1 "Wired Ethernet Connection" -ServerAddresses 192.168.40.21, 192.168.40.22
```

## Task 7 – Cleaning up (Optional)

1. Delete ISO files after installation